

# SUMAR AUTO SPARE PARTS TRADING (L.L.C.)

[www.sumarauto.com](http://www.sumarauto.com)

[info@sumarauto.com](mailto:info@sumarauto.com)

S/N	Part No	Description
1	43448-06120-YA	DRIVE SHAFT BOOT (INNER)
2	43447-35040-YA	DRIVE SHAFT BOOT (OUTER)
3	43448-35030-YA	DRIVE SHAFT BOOT (INNER)
4	04438-60010-YA	DRIVE SHAFT BOOT
5	45536-14020-YA	STEERING GEAR BOOT (RH)
6	43447-28020-YA	DRIVE SHAFT BOOT (OUTER)
7	43447-60040-YA	DRIVE SHAFT BOOT
8	MR528709-YA	DRIVE SHAFT BOOT (INNER)
9	43447-35021-YA	DRIVE SHAFT BOOT (OUTER)
10	43448-35020-YA	DRIVE SHAFT BOOT (INNER)
11	48157-06060-YA	SHOCK DUST COVER (FR)
12	45535-06040-YA	STEERING GEAR BOOT
13	YB01-1067	SHOCK DUST COVER (RE)+2
14	YB01-1061	SHOCK DUST COVER (FR)+1
15	53534-SR3-N52-YA	STEERING GEAR BOOT (POWER)
16	MB896069-YA	DRIVE SHAFT BOOT (OUTER)
17	MB886676-YA	DRIVE SHAFT BOOT (INNER)
18	43448-52020-YA	DRIVE SHAFT BOOT (INNER)
19	43448-0K020-YM	DRIVE SHAFT BOOT (INNER)+1
20	39241-0F000-YA	DRIVE SHAFT BOOT (OUTER)
21	39741-0F000-YA	DRIVE SHAFT BOOT (INNER)
22	43448-12120-YA	DRIVE SHAFT BOOT (INNER)
23	48341-32090-YA	SHOCK DUST COVER (RE,RH,LH)
24	MB160657-YA	DRIVE SHAFT BOOT (OUTER)
25	MB160658-YA	DRIVE SHAFT BOOT ( INNER )
26	43447-17011-YA	DRIVE SHAFT BOOT (OUTER)
27	39241-10E88-YA	DRIVE SHAFT BOOT (OUTER)
28	48257-06020-YA	SHOCK DUCT COVER